

Lemvig

1. Location

2.7 NM S of Lemvig

2. Address

Lemvig Kommune
DK-7620 Lemvig

TEL Administration: +45 96 63 12 00
TEL AD: +45 97 82 13 68

3. Approved for

- VMC day operations
- Self-service only

4. Operational hours

AD: Daily SR-SS (Daily SR-SS)
ARO: Submission of flight plan:
Briefing EKCH TEL: +45 32 47 82 72
FAX: -
Closing a flight plan/
ACC TEL: +45 32 46 23 38
MET: TEL: +45 39 15 72 72
FAX: +45 39 27 10 80

5. Customs/Immigration

The aerodrome is open for traffic to/from all States.
Customs clearance and immigration available only
by arrangement with AD, TEL +45 97 82 13 68.

6. Fuel, Oil and De-icing Fluid, etc.

Fuel: No
Oil: No

7. Hangar Space for Visitors

No

8. Repair Facilities Available

No

9. Rescue and Fire Fighting Service

Not available, see AD 1.2-1 concerning limitations.

10. Seasonal Availability

All seasons

11. Hotel

In town

12. Restaurant

In town

13. Tourist Office

Lemvig TEL: +45 97 82 00 77

14. Medical Facilities

-

15. Transport

-

16. Local Regulations/Remarks

- RWY 08 is preferential runway, when wind conditions so permit.
- After take-off RWY 26 overflying Lomborg town should be avoided.
- For landing exercises PPR from the aerodrome (TEL +45 97 82 13 68).
- Launching of gliders by cable may take place. When gliding is taking place, overflying the aero

1. Beliggenhed

2.7 NM S for Lemvig

2. Adresse

Lemvig Kommune
7620 Lemvig

TEL Administration: 96 63 12 00
TEL AD: 97 82 13 68

3. Godkendt til

- VMC dag operationer
- Kun selvbetjening

4. Tjenestetider

AD: Dagligt SR-SS (Dagligt SR-SS)
ARO: Afgivelse af flyveplan:
Briefing EKCH TEL: 32 47 82 72
FAX: -
Afslutning af flyveplan:
ACC TEL: 32 46 23 38
MET: TEL: 39 15 72 72
FAX: 39 27 10 80

5. Told/Pas

Flyvepladsen er åben for trafik til/fra alle lande. Told-
og paskontrol kun efter forudgående aftale med AD,
TEL 97 82 13 68.

6. Brændstof, olie og afisningsvæske m.m.

Brændstof: Nej
Olie: Nej

7. Hangarplads for besøgende

Nej

8. Reparationsmuligheder

Nej

9. Brand og redningstjeneste

Ikke etableret, se AD 1.2-1 vedrørende begrænsninger.

10. Sæsonmæssig anvendelighed

Hele året

11. Hotel

I byen

12. Restaurant

I byen

13. Turistkontor

Lemvig TEL: 97 82 00 77

14. Lægehjælp

-

15. Transport

-

16. Lokale regler/Bemærkninger

- RWY 08 er præference bane, såfremt vindforholdene tillader det.
- Efter start på RWY 26 bør overflyvning af Lomborg undgås.
- Landingsøvelser er kun tilladt efter tilladelse fra flyvepladsen (TEL 97 82 13 68).
- Spilstart af svævefly kan finde sted. Når der foregår svæveflyvning, bør pladsen ikke over-

- drome should be avoided below 2000 FT MSL.

e.

Gliders shall use frequency 123.405 MHZ during take off/landing and traffic circuit.

f.

Runway classification

RWY NR	RWY CODE	TYPE
08	1C	NINST
26	1C	NINST
- flyves under 2000 FT MSL.

e.

Svævefly under start/landing og i landingsrunden anvender frekvensen 123.405 MHZ.

f.

Baneklassifikation

RWY NR	RWY KODE	TYPE
08	1C	NINST
26	1C	NINST