

ENR 4.4 Name-Code Designators for Significant Points**1. IFR Significant Points**

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
ABINO	555806N 0095940E	P615, T56	(DI)	(D): EKBI
ABKAS	553548N 0080806E	L975	(I)	
ADIKU	552050N 0041759E	KY610		
ADSEN	560841N 0105302E	M852, M725	(I)	Re-routing point
ADUNU	550000N 0051217E	KY776		
ADVOP	560714N 0120702E	Z703	(I)	Re-routing point
ALASA	544831N 0095742E	M611, M852	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
AMADA	550000N 0062100E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
AMRAK	544928N 0094502E	P999	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
AMRAM	555637N 0063803E	L983, N866, P60	(I)	Re-routing point
AMSEV	574031N 0084808E	L621, P602	(I)	
AMSUR	560602N 0123350E	T402	(I)	
AMTID	560355N 0043042E	KY877, KY882		
AMTOT	560226N 0121049E	Z702	(I)	
ANESI	552746N 0070000E	KY773, KY777, KY875		
ARBAG	554718N 0060000E	KY877		
ARTOR	582004N 0100856E	P615	(I)	
ARVIG	552623N 0082849E	KY875		
ASBIL	552219N 0095938E	L983, P615	(I)	
ASKEG	553310N 0112346E	L975	(I)	
ASKEK	554726N 0035934E	KY610, KY615		
ASLID	562047N 0112038E	T505, P990	(I)	Re-routing point
ASMUS	550500N 0083931E	P992	(I)	Re-routing point
ASVAN	560000N 0115600E	Z703	(I)	Re-routing point
ATNAK	570000N 0050000E	N/A	(I)	
ATTUS	545359N 0084658E	P992	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
BAGOS	543422N 0111612E	N850	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
BAKOG	560459N 0081420E	M609	(I)	
BAMPI	555034N 0081611E	M609, P60	(DI)	(D): EKBI
BANLU	552935N 0081445E	KY877		

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
BAVIL	553439N 0082948E	P614	(I)	
BAVTA	553611N 0081800E	L975, L983, M609, N607, N873, P601, P602, P613, P619, P992, T56, Z708, Z709, Z710, KY876	(I)	
BEBUL	554846N 0091521E	T56	(I)	Re-routing point
BEDRO	553552N 0060000E	KY876		
BEGAK	550000N 0072213E	KY782		
BELAP	552906N 0035946E	KY615		
BELUV	552741N 0043259E	KY875, KY889, KY980		
BETUD	550026N 0123121E	L983, EKCH SID	(DI)	(D): EKCH, EKRK
BEVUM	560149N 0115846E	Z703	(I)	
BINRO	580938N 0094710E	T551	(I)	
BISTA	551212N 0120723E	M725	(I)	
BUSOM	555631N 0052341E	L983, M604, P144	(I)	
DANKO	570000N 0064152E	M604, P15, P850	(I)	
DANOR	561207N 0033843E	KY980		
DANUM	550000N 0051653E	KY980		
DAVAL	552814N 0052804E	KY875		
DEMIR	545011N 0095110E	N872	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
DETNA	573515N 0110409E	N866, ESGG SID	(DI)	(D): ESGG
DIKAT	551240N 0043432E	KY776		
DINOK	552330N 0075052E	KY779, KY789, KY875, KY884, KY893		
DISGO	550906N 0124401E	T508	(I)	
DOBEL	553622N 0112324E	N872	(I)	
DOREV	553200N 0073500E	N/A	(I)	Re-routing point
DOROR	550000N 0070918E	KY777	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
DOSUR	545131N 0091139E	P729	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
EBAVA	544300N 0104200E	N/A	(I)	Re-routing point
EBUSA	550000N 0055409E	KY781		
EKDIV	554149N 0112247E	Z703	(I)	
EKMOL	550503N 0073443E	KY779, KY782		
ELMIG	553809N 0080845E	L983	(I)	
ELVAV	575758N 0105735E	N/A	(I)	Re-routing point

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
EMBEG	560238N 0045338E	KY877, KY995		
EPILO	554940N 0082444E	P60, P601, P614	(I)	Re-routing point
ERGAT	560337N 0091818E	P622	(I)	
ERITO	554831N 0080712E	KY878		
ESBOZ	553041N 0082446E	KY877		
ETVOK	570300N 0093600E	N/A	(I)	Re-routing point
EVAKI	561422N 0072852E	N866, P619, T55	(I)	Re-routing point
EVBAS	560844N 0122840E	Z702	(I)	
EVBED	551351N 0123740E	L990	(I)	
EVGUN	581616N 0100057E	N/A	(I)	Re-routing point
EVKAN	550000N 0073744E	KY779		
EVSES	572229N 0093759E	N/A	(I)	Re-routing point
GARKA	554635N 0052540E	N/A	(I)	
GAVPU	555244N 0081827E	KY892		
GEGDA	554624N 0041026E	KY980		
GELTI	544726N 0100000E	N/A	(I)	Re-routing point
GESKA	543703N 0115557E	N851, P605, Q280, T59, Z706, Z711	(I)	
GIDLA	545900N 0085500E	N/A	(I)	Re-routing point
GIGUT	555544N 0094815E	T56	(I)	
GIKIV	560356N 0090708E	N873	(I)	
GIMRU	543336N 0111849E	T503	(EXDI)	(D): EKCH, EKRK. Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
GITER	543840N 0110000E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
GOBOT	543722N 0110510E	N/A	(EXDI)	(D): EKCH, EKRK. Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
GODOG	561603N 0105832E	M852, T148, T505	(I)	
GOLGA	561959N 0114142E	T505, T506, EKCH SID	(DI)	(D): EKCH, EKRK Re-routing point
GOLMI	554638N 0123059E	N850, T402	(I)	
GOLUM	552700N 0051700E	L39, L975, N866, P144, P850	(I)	Re-routing point
GOMLA	553447N 0044532E	KY876, KY886, KY889		
GOREV	560312N 0050000E	M869	(I)	
GOTEX	571218N 0111622E	N873, Z731	(AI)	(A): ESGG

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
GOVRA	550412N 005000E	KY776		
GREFI	550000N 0055132E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
GURLI	582528N 0103358E	N/A	(I)	Re-routing point
HINSE	563352N 0074141E	N/A	(I)	Re-routing point
IBNIL	552141N 0113038E	T59	(I)	
IBOTA	552906N 0080955E	KY875, KY877		
IBREK	562330N 0121356E	M869	(I)	
IBUKA	552600N 0085500E	N/A	(I)	Re-routing point
INBOB	553625N 0050000E	M604	(I)	
INLAN	560501N 0081929E	P614	(I)	
INPUN	554704N 0112211E	N603, M725	(I)	
INSUS	551330N 0080157E	N/A	(I)	Re-routing point
INTET	561335N 0092441E	N873, T55	(DI)	(D): EKBI
INVOL	573916N 0111317E	N866	(I)	
IPSUB	550000N 0075711E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
IRKAM	560445N 0083222E	P601	(I)	
JONAZ	572100N 0100706E	N/A	(I)	Re-routing point
JUTZU	551400N 0072000E	KY893		
KARLI	570000N 0053027E	P613, T505	(I)	
KASFI	553526N 0123649E		(I)	
KEMEG	564315N 0085221E	N866, P601	(I)	Re-routing point
KESUR	545026N 0095315E	Z703	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
KETAL	551605N 0112158E	T59	(I)	
KOKAK	552929N 0124254E	L975	(I)	
KOKOR	542741N 0114124E	Z706	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
KOPEX	545813N 0112804E	M611, T58, EKCH SID	(DI)	(D): EKCH, EKRK
KOPIIM	560802N 0122954E	N872	(I)	
KOSEB	544648N 0123552E	T298	(EXAI)	(A): EKCH. Only AVBL as Intermediate for traffic from/to aerodromes in DK-SE FAB
KOSMO	550055N 0124349E	L983, P605	(I)	
KOVIK	573335N 0083427E	P990	(I)	
KUBIS	551323N 0122854E	N851	(I)	

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
KUGAL	550000N 0073714E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
KULUD	561538N 0121959E	L621, Z703	(ADI)	(A): ESMS (D): ESMS, ESTL
KUNAR	553623N 0070000E	KY876, KY877		
KUVUS	572017N 0110000E	N607	(AI)	(A): ESGG
LAGUM	572720N 0091606E	L621, P601	(I)	Re-routing point
LANGO	545644N 0105123E	M611, P999, EKCH SID	(DI)	(D): EKCH, EKRK
LAPMA	563733N 0112051E	L621, T506	(I)	
LASGI	560648N 0122716E	N872	(I)	
LASRO	560423N 0084850E	N607	(I)	
LAVMA	552947N 0043641E	KY889		
LEBDA	552225N 0123743E	N851	(I)	
LESRA	552308N 0050000E	L975	(I)	
LILBI	551511N 0124058E	L990	(I)	
LINVI	570000N 0071338E	L39, P992	(I)	
LOBBI	571905N 0112953E	N873, ESGG STAR	(I)	
LOMPU	543532N 0111210E	T148	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
LUGAS	551947N 0105747E	P729	(I)	Primary holding, EKCH
LUPUR	545928N 0120303E	L990, M611	(I)	
LUTAN	552812N 0060000E	KY781, KY875		
LUTIR	550351N 0082458E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
LUTUS	560603N 0095940E	M602, P615, T55	(I)	
MADAG	562250N 0120049E	L621, M869	(I)	Re-routing point
MAKEL	542658N 0114801E	N851	(EXAI)	(A): EKCH, EKRK, ESMS. Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
MAKUR	572547N 0112425E	N607, ESGG STAR	(I)	
MARIP	544323N 0112515E	L990, N850, Z701	(I)	
MATEK	550059N 0124803E	L983	(I)	Re-routing point
MAXEL	551233N 0115409E	N850, EKCH SID	(I)	
MEGAR	542806N 0113854E	P605	(EXAI)	(A): EKCH, EKRK, ESMS. Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
MIKRO	552454N 0080959E	KY875, N873	(DI)	(D): EKBI Re-routing point
MIKSI	561210N 0113527E	P990	(I)	Re-routing point

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
MISBI	555355N 0124021E	N850	(I)	
MITSI	570000N 0062721E	P619	(I)	
MONAK	545644N 0121849E	Q296, T298, Z711, EKCH STAR	(I)	
MOSAT	550231N 0124717E	P605	(I)	
NAMIK	562253N 0052627E	P60	(I)	
NAMON	561807N 0043611E	KY878, KY885		
NARBA	555112N 0080650E	P60, P992	(I)	
NARIG	561500N 0050000E	KY878		
NAROL	560021N 0121330E	N872	(I)	
NARSU	560700N 0060000E	KY878, KY881		
NAVDA	553534N 0095456E	L975	(I)	
NAVIK	555147N 0075811E	P60, P619	(I)	Re-routing point
NAVNI	552751N 0043930E	KY875		
NEBSA	554630N 0081700E	KY878		
NEBUM	555000N 0080000E	KY878, KY879		
NEDIK	542911N 0120354E	Q280	(EXI)	Only AVBL as Intermediate for traffic from/to aerodromes in DK-SE FAB
NERDO	575317N 0091342E	P621	(I)	
NEXEN	544839N 0113731E	L990, T503, EKCH SID	(DI)	(D): EKCH, EKRK
NIKDA	543631N 0121708E	Q296	(EXAI)	(A): EKCH. Only AVBL as Intermediate for traffic from/to aerodromes in DK-SE FAB
NIROD	580443N 0093700E	P601	(I)	
NIROX	555830N 0070000E	KY878		
NISEM	553929N 0095456E	P60	(I)	
NOREM	570000N 0054612E	KY994		
NORSO	570000N 0051030E	KY995		
NORTI	563128N 0113732E	L621	(I)	Re-routing point
NOVPO	560624N 0121428E	L997, EKCH SID	(I)	
NUGLO	555231N 0074652E	P60, P613	(I)	
NUSRI	551428N 0070000E	KY777, KY884		
ODARU	550545N 0124541E	M611	(I)	
ODDON	553452N 0103911E	L975, M602, P60	(DI)	
ODNAN	552431N 0080014E	KY875		
OKMAM	565346N 0063557E	P619, P850	(I)	Re-routing point

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
OKTIR	554317N 0044807E	KY882, KY887, KY995		
OKVED	555700N 0081300E	KY892		
OLPIB	550005N 0122245E	L983, M602, M611, M725, M869, P730, Z711	(DI)	
OMIMA	550000N 0063655E	KY773	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
OMIRI	562858N 0045440E	KY879, KY881, KY885		
ORTUT	555828N 0080542E	KY892		
OSBAR	560449N 0041349E	KY877, KY885		
OSGAM	571600N 0090800E	P601	(I)	Re-routing point
OSKEV	552429N 0112622E	P729	(I)	
OTRAL	562039N 0041619E	KY878, KY882		
PEGAM	552701N 0075036E	KY779, KY787, KY789, KY875, KY877, KY884		HEL SID EKEB
PEMAD	555900N 0043453E	KY882		
PEPUT	551158N 0120301E	Z706	(I)	
PETIL	555620N 0050000E	L983	(I)	
PEVOR	560455N 0082440E	P602	(I)	
POGUG	545000N 0103602E	N/A	(I)	Re-routing point
RADIS	563230N 0095942E	N873, P615	(I)	
RAMUD	570326N 0073626E	P614	(I)	
RASVI	571723N 0080258E	M609	(I)	
RAXLU	544256N 0101625E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
RERPA	562842N 0081115E	M609, N866, P614, T505	(DI)	(D): EKBI
RERSO	553615N 0080826E	KY876		
RETKA	575929N 0092619E	P622	(I)	
REXMI	550000N 0074447E	N873	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
RIDSI	553530N 0095939E	L975, P615, EKBI SID	(DI)	(D): EKBI
RIPRO	552821N 0080254E	KY875, KY877		
ROBUS	550634N 0114311E	L983, M602, T59, T508	(I)	
ROKAM	561901N 0121100E	L621, L997	(AI)	(A): ESGG Re-routing point
ROLVA	553622N 0042929E	KY874, KY876		
ROSB1	555058N 0105555E	N603	(I)	Re-routing point
RUVUD	553046N 0082546E	N/A	(I)	Re-routing point

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
SISPU	561112N 0070000E	KY879, KY892		
SISRA	561942N 0060000E	KY879		
SISVI	562814N 0050000E	KY879		
SIVSU	552819N 0091706E	L983	(I)	
SONAL	545244N 0124649E	M602, M725	(EXAI)	(A): EKRK. Only AVBL as Intermediate for traffic from/to aerodromes in DK-SE FAB
SOPTO	551820N 0050000E	P144	(I)	
SORDA	551046N 0050000E	KY980		
SUNEX	553154N 0045424E	KY886		
SURIR	552544N 0082517E	P992	(I)	
SUTEB	550000N 0052508E	N/A	(EXI)	Only AVBL as intermediate for traffic from/to aerodromes in DK-SE FAB.
TABAP	552813N 0055612E	KY875, KY994		
TAGIM	554819N 0055405E	KY877, KY994		
TALSA	550625N 0094111E	P729, P730, Z702	(AI)	(A): EKCH, EKRK
TALUL	562105N 0055032E	KY879, KY994		
TESPI	555354N 0103152E	N603, T55, T56, T551, EKCH STAR	(AI)	(A): EKCH Primary Holding, EKCH
TINAC	561503N 0050000E	T55	(I)	
TITOG	554541N 0070000E	KY881		
TOMGU	554709N 0090747E	P622	(I)	
TOTSA	550000N 0055907E	KY994		
TUDLO	551633N 0103852E	L983, P729, T153, EKCH STAR	(AI)	(A): ESMS
TUSKA	550000N 0075234E	KY789		
TUTNU	550000N 0064909E	KY787		
TUXEN	553527N 0052938E	KY876, KY887, KY888		
UNVUG	575700N 0102300E	N/A	(I)	Re-routing point
UPGAS	551441N 0050000E	N866	(I)	
URUBO	565400N 0073400E	N/A	(I)	Re-routing point
USULI	551044N 0064004E	KY773, KY787		
VABOB	562416N 0045953E	KY995		
VADIN	570816N 0113838E	M852, ESGG SID	(DI)	(D): ESGG
VAGAX	555923N 0045242E	KY995		
VALBO	550744N 0050000E	N/A	(I)	

AIP DENMARK

Name Code Designator	Coordinates	ATS Route or Other Route	FRA relevance E= Horizontal Entry Point X= Horizontal Exit Point A= Arrival Connecting Point D= Departure Connecting Point I = Intermediate Point	Remarks / Usage
VAXIT	563215N 0050000E	N581, P15, P60	(I)	
VEDAR	563154N 0120725E	L997, EKCH SID	(DI)	(D): EKCH, EKRK
VESUV	554300N 0044501E	KY874, KY886		
WOZNI	552809N 0050759E	KY875, KY886, KY888		

2. VFR Reporting Points near Aerodromes

AD	REP	PSN
Aalborg	Biersted Hasseris Svenstrup Vildmosen	57 09 19N 009 49 24E 57 02 07N 009 49 55E 56 57 38N 009 51 55E 57 13 01N 009 50 13E
Aarhus	Ebeltoft Grenaa Knebel Langsø Nøddager Ryomgård	56 09 58N 010 40 26E 56 22 28N 010 50 56E 56 13 28N 010 26 56E 56 15 58N 010 36 56E 56 20 28N 010 37 26E 56 23 18N 010 26 55E
Billund	Egtved Give Karlskov Vandel Vorbasse	55 37 36N 009 17 52E 55 50 22N 009 10 42E 55 47 24N 009 10 42E 55 41 30N 009 10 30E 55 38 24N 009 04 14E
Bornholm/Rønne	Dueodde Hasle	54 59 28N 015 05 01E 55 11 38N 014 42 36E
Esbjerg	Gørding Skads Store Darum Varde Vester Nebel Dorid	55 28 23N 008 49 20E 55 30 40N 008 33 46E 55 24 53N 008 37 45E 55 37 28N 008 30 55E 55 32 26N 008 32 38E 55 31 10N 008 00 00E
Karup / Midtjyllands Lufthavn	Ikast Ilskov Kongenshus Sjørup	56 08 18N 009 07 55E 56 13 58N 009 06 46E 56 23 00N 009 07 56E 56 26 28N 009 08 45E
København/Kastrup	Holding West Tuborg Vallensbæk	55 36 48N 012 29 41E 55 42 58N 012 35 56E 55 36 43N 012 21 56E
København/Roskilde	Borup Ishøj Køge Valby	55 30 43N 011 58 26E 55 38 08N 012 17 21E 55 28 43N 012 08 16E 55 41 36N 012 08 02E
Odense / Hans Christian Andersen Airport	Bogense Lindø Lumby Stensby Vissenbjerg	55 34 40N 010 11 00E 55 27 25N 010 33 00E 55 28 00N 010 22 00E 55 30 00N 010 18 00E 55 24 05N 010 08 10E
Stauning	Lem North Skjern West South	56 01 48N 008 23 55E 56 00 36N 008 21 30E 55 56 38N 008 28 25E 55 59 00N 008 22 06E
Sønderborg	Bovrup Broager Bøjden Fynshav Gelting Nordborg Ærø North	54 59 33N 009 35 26E 54 54 18N 009 40 36E 55 04 40N 010 04 25E 54 59 45N 009 58 24E 54 45 16N 009 53 44E 55 03 58N 009 48 26E 54 57 58N 010 11 56E