Introduction

The following information is extracted from AIP Denmark and VFR Flight Guide Denmark (VFG) and corrects to ICAO ANC 1:500 000 DENMARK (ANC) dated 16 APR 26. The ANC dated 16 APR 26 is published in paper and digital. The digital version will continuously be updated by AIRAC dates. The paper version will be updated once a year.
This document and latest ANC can be found on the Internet: https://aim.naviair.dk

Aerodromes. Availability

Public Aerodromes

The Danish public aerodromes are open for traffic to and from other States as indicated on the list below.

Customs clearance is compulsory for all flights to Denmark. Immigration is compulsory except for flights between the Schengen States.

List of Schengen States:

Austria, Belgium, Bulgaria, Croatia, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Italy, Latvia, Lichtenstein, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and The Czech Republic.

Civil use of Military Air Bases

General

Use of military air bases in Denmark with other than State registered aircraft may be made solely when prior permission has been obtained.
The use of military air bases as an alternate aerodrome may likewise be made solely when prior permission has been obtained.
Aalborg Air Base is not affected by these regulations.
Permission to use Karup Air Base will be granted unless special conditions may be regarded as prohibitive.
As regards other air bases a permission may be granted only if the conditions are favourable.
A permission may at any time be withdrawn with immediate effect, should circumstances so require.

Submission of Application

Application in writing for permission to use a military air base shall be submitted direct to the air base concerned well in advance of the intended date of flight.

Addresses

Karup Airport, Airport Office, N.O. Hansenvej 4, DK-7470 Karup J.
TEL: +45 97 10 06 10, FAX: +45 97 10 06 65.

Vojens/Skrydstrup Airport, Lilholtvej 8, Skrydstrup, DK-6500 Vojens
TEL: +45 74 59 18 54, FAX: +45 74 54 00 06.
E-mail: airport@vojens.dk
Application form is available on the Internet: http://vojenslufthavn.dk

Rules and Conditions

Operations on the air base must be carried out in accordance with the rules and conditions stated in the following with due regard to such other conditions as may have been stipulated for each individual permission.

a. A flight plan shall be submitted for each flight. During flight in controlled airspace and during operations on the manoeuvring area, the pilot-in-command shall closely observe the directions given.

b. The Commander of the Air Base lays down the rules which are to be observed by flight crew members and passengers concerning security measures, traffic and stays at the air base. As regards to the Air Bases Karup (Karup/Midtjylland Airport) and Skrydstrup (Vojens/Skrydstrup), photographing from the air as well as on the ground is prohibited. At the remaining air bases the local ban on photographing will apply, as published by posters.
Flight crew members, respectively ground personnel, shall immediately report to the air base in case it is surmised that the ban on photographing has been violated.

c. The Defence Forces shall not be liable for the death, and fire-, water- or other damage to aircraft, their equipment, flight crew members, passengers, cargo, etc., caused during stays at the air base.
The Defence Forces reserve their right to claim compensation for damage caused by civil aircraft, flight crew members or passengers to the Air Force material, buildings and personnel within the area of an air base.

d. Landing- and other charges will be collected in accordance with the provision of the current "Tariff Regulations applying to Public State-operated Airports in Denmark" approved by the Ministry of Transport.

Karup Air Base. Special Regulations

Request on permission for individual flights to use the military Karup Air Base, within the civilian Karup Airport ATS Reporting Office hours can be made by phone or telefax, as late as the date-of-flight.
As regards other air bases a permission may be granted only if the conditions are favourable.
A permission may at any time be withdrawn with immediate effect, should circumstances so require.

Submission of Application

Application in writing for permission to use a military air base shall be submitted direct to the air base concerned well in advance of the intended date of flight.

Addresses

Karup Airport, Airport Office, N.O. Hansenvej 4, DK-7470 Karup J.
TEL: +45 97 10 06 10, FAX: +45 97 10 06 65.

Vojens/Skrydstrup Airport, Lilholtvej 8, Skrydstrup, DK-6500 Vojens
TEL: +45 74 59 18 54, FAX: +45 74 54 00 06.
E-mail: airport@vojens.dk
Application form is available on the Internet: http://vojenslufthavn.dk

Rules and Conditions

Operations on the air base must be carried out in accordance with the rules and conditions stated in the following with due regard to such other conditions as may have been stipulated for each individual permission.

a. A flight plan shall be submitted for each flight. During flight in controlled airspace and during operations on the manoeuvring area, the pilot-in-command shall closely observe the directions given.

List of Public Aerodromes

Aerodrome	Open for Traffic to/from	TEL: +45	FAX: +45	Remarks
Aalborg - EKYT	All States	98 17 11 44	98 17 36 84	"Aalborg Handling": FREQ 131.555 MHZ. Outside stated hours PPR for non-scheduled flight shall be submitted to airport office not later than 2100 (2000), and for ambulance flights 1 HR prior. (Please note that an extra fee will be charged). *Aarhus Airport Office": FREQ 131.555 MHZ. PPR outside AD hours for non-scheduled flights and PN for scheduled flights submitted to ADO. *Self-service AD. Customs: PN 1 HR on tel.: +45 21 54 57 57. Company FREQ 131.500 MHZ. Call sign "AIRCAT/AANCLT".
Aarhus - EKAH	All States	87 75 70 50	87 75 70 52	
Arnholt - EKAT *	Schengen States	46 19 11 14		
Billund - EKBI	All States	76 50 50 50		"Bornholm Handling": FREQ 131.550 MHZ. Customs/Immigration: PN 1 HR. *Esbjerg Handling": 131.555 MHZ. Customs/Immigration: Are available when AOD is established. PN 1 HR. *Self-service AD.
Bornholm/Rønne - EKRN	All States	56 95 36 26		
Esbjerg - EKEB	All States	76 16 90 00		
Henning - EKHG	All States	97 14 12 44		
Kalundborg - EKKL *	National AD	ADO: 20 45 49 11 40 41 12 26 40 10 88 85 ADM: 33 32 33 11	97 10 06 65	
Karup/Midtjylands Lufthavn - EKKA Kolding/Vamdrup - EKVD	All States All States	97 10 06 10 75 58 18 77		MIL AD PPR. "Karup Airport Office": 131.550 MHZ. PPR 1 HR PN for ADA/DO/AFS submitted 1 HR before closing time. PPR not permitted outside AFIS hours. Customs/Immigration: PN 1 HR. Remark: for flight originated outside Denmark with destination inside Denmark must state number of PAX of Schengen and non-Schengen citizens onboard in flight plan item 18.
Kløvtoft-Padborg - EKPB *	National AD	30 56 53 23		*Self-service AD. SR - SS or civil twilight. VFG Night: PPR TEL: +45 30 56 53 03.
København/Kastrup - EKCH	All States	32 31 24 72		*Self-service AD. Customs: PN 1 HR.
København/Roskilde - EKRK	All States	32 31 32 31		Customs/Immigration: PN 1 HR. "Roskilde Handling": 131.555 MHZ.
Lemvig - EKLV *	All States	97 82 13 68		*Self-service AD. Customs/Immigration by arrangement TEL +45 97 82 13 68.
Lolland Falster/Maribo - EKMB	All States	54 60 61 13		Customs/Immigration: PN 1 HR to ADO.
Læsø - EKLS *	Schengen States	24 98 35 95		*Self-service AD. Customs: PN 1 HR available MON-WED 0700-1430 (0600-1330), THU 0700-1630 (0600-1530) and FRI 0700-1200 (0600-1100) on TEL +45 72 22 12 12.
Morsø - EKNM *	National AD	ADM: 20 33 17 71 ADO: 51 21 21 73 AD: 20 66 56 65		*Self-service AD.
Odense/Hans Christian Andersen Airport - EKDO	All States	65 95 50 72		Customs/Immigration: PN 1 HR.
Randers - EKRD	Schengen States	86 40 40 11	86 43 41 82	Customs/Immigration: PN 1 HR on E-mail: aarhus.toldkontrol@toldst.dk. The request for customs clearance and immigration shall contain following information: DEP AD, CS, PIC, PAX and ETA.
Ringsted - EKRS *	Schengen States	20 29 34 28		*Self-service AD. Customs: PN 1 HR on FAX: 57 65 16 00. The request for custom clearance and immigration shall contain following information: DEP AD, CS, PIC, PAX and ETA.
Samsø - EKSS *	National AD	40 16 40 44		*Self-service AD.
Sindal - EKSN	All States	98 93 58 00		PPR outside AD hours for ADO submitted to TEL: +45 98 93 58 00. Customs/Immigration: PN 1 HR to ADO.
Skive - EKSV	All States	61 29 57 77 (mobile)		PPR outside AD hours for ADO/AFIS submitted no later than 2 HR before closing time. Customs/Immigration: PN 2 HR on TEL +45 61 29 57 77. PN shall be submitted MON-FRI 0900-1500 (0800-1400).
Stauning - EKVJ	All States	97 36 90 44		PPR 1 HR PN for AFIS outside ARO service hours. PPR must be submitted not later than 1 HR before ARO closing time. Customs/Immigration: PN 1 HR before ARO closing time. IFR traffic is not permitted outside AFIS service hours. *Self-service AVBL for aircraft MTOW BLW 2000KG VFR outside opening hours.
Sønderborg - EKSB	All States	74 42 21 30		PPR outside AD hours for ADA/DO/AFIS submitted not later than 2 HR before closing time to ADO. Customs/Immigration: PN 1 HR.
Thisted - EKTS *	All States	99 17 37 80		*Self-service when ADO is closed. Customs: PN 1 HR.
Tønder - EKTD	Schengen States	74 72 28 55		Customs: PN 1 HR to +45 74 72 28 55.
Tåsinge/Elvira Madigan Airport - EKST	All States	62 54 22 94	62 53 33 49	PPR outside AD hours for AD/ADO submitted not later than 2 HR before closing time to ADO on TEL +45 62 54 22 94. Customs/Immigration: PN 2 HR.
Vesthimmerland - EKVH *	All States	99 66 73 85		*Self-service AD. PPR outside AD hours (daily 0700-1900 (0500-1700)) to TEL: +45 99 66 73 85. Customs/Immigration: PN 1 HR to ADO. PN shall be submitted MON-FRI 0900-1500 (0800-1400), THU 1000-1700 (0800-1600) and FRI 1000-1200 (0800-1100).
Viborg - EKVB	Schengen States	86 60 18 60		PPR outside AD hours for ADO submitted not later than 1 HR before closing time to ADO. Customs: PN 1 HR to ADO.
Vojens/Skrydstrup - EKSP	All States	74 59 18 54	74 54 00 06	MIL AD PPR. Customs/Immigration: PN 1 HR.
Ærø - EKAE	All States	ADI: 63 52 63 67 ADM: 63 52 50 00	62 53 33 49	PPR outside AD hours for AD/ADO submitted not later than 1 HR before closing time to ADO. Customs/Immigration: PN 1 HR to ADO.

VFR Reporting Points near Aerodromes

AD	REP	PSN	AD	REP	PSN
Aalborg	Biersted Hasseris	57 09 19N 009 49 24E 57 02 07N 009 49 55E	København/Kastrup	Holding West Tuborg	55 36 48N 012 29 41E 55 42 58N 012 36 56E
	Svenstrup Vidmosen	56 57 38N 009 51 55E 57 13 01N 009 50 13E		Vallensbæk	55 36 42N 012 21 58E
Aarhus	Ebeltoft Egå Bugt Knebel Langaa Norsager Ryomgård	56 09 58N 010 40 26E 56 12 00N 010 24 00E 56 13 28N 010 26 56E 56 16 58N 010 36 56E 56 22 28N 010 37 26E 56 23 18N 010 26 55E	København/Roskilde	Barup Høje Kaga Valby	55 30 43N 011 58 26E 55 38 08N 012 17 21E 55 28 43N 012 08 18E 55 41 36N 012 08 02E
Billund	Egtved Fredericia Kærkiov Vandel Vorbasse	55 37 36N 009 17 52E 55 54 00N 009 47 00E 55 47 24N 009 10 42E 55 41 30N 009 10 30E 55 38 24N 009 04 14E	Odense/Hans Christian Andersen Airport	Bogense Broby Lumby Stenslev Vissenbjerg	55 34 40N 010 11 00E 55 27 00N 010 33 00E 55 29 00N 010 22 00E 55 30 00N 010 18 00E 55 24 00N 010 08 10E
Bornholm/Rønne	Dueodde Hasle	54 59 28N 015 05 01E 55 11 38N 014 42 36E	Stauning	Lem North Oksbøl-West South	56 01 48N 008 23 55E 56 00 36N 008 21 30E 55 54 00N 008 23 00E 55 59 00N 008 22 26E
Esbjerg	Dorld Gerding Skads Store Darum Varde Vester Nebel	55 31 10N 008 00 00E 55 28 23N 008 49 20E 55 30 40N 008 33 46E 55 24 53N 008 37 49E 55 37 28N 008 30 55E 55 32 26N 008 32 38E	Sønderborg	Bovrup Broager Bøjden Fynshav Gelting Nordborg Øl'ø North	54 59 32N 009 35 26E 54 54 18N 009 40 36E 55 04 40N 010 04 23E 54 59 49N 009 58 24E 54 45 19N 009 53 44E 55 03 58N 009 46 26E 54 57 58N 010 11 54E
Karup/Midtjylands Lufthavn	Ikast Ikkiov Kongenshus Sjerup	56 08 18N 009 07 55E 56 13 58N 009 06 46E 56 23 00N 009 07 56E 56 26 28N 009 08 46E			

List of Radio Navigation Aids

ID	FAC	PSN	Designated Operational Coverage and other INFO	ID	FAC	PSN	Designated Operational Coverage and other INFO
Denmark				ROE	TACAN 112.200/37X	55 03 42.72N 014 45 21.07E	FL 50/60NM DME ELEV 78.6 FT
AAL	VOR 116.700	57 06 13.36N 009 39 44.08E	FL 50/120 NM. DME INFO from AAL TACAN Unreliable in the sector from radial 160 to radial 200 in a distance of 23 NM from the VOR and out.	SKR	TACAN 110.400/41X	55 13.44N 181 009 12 50.61E	FL 50/60 NM DME ELEV 136.4 FT
AAL	TACAN 116.700/114X	57 06 14.16N 009 39 34.11E	FL 50/60 NM DME ELEV 56.8 FT	SN	DME 24x	55 35 13.15N 012 08 06.64E	DME ELEV 167.3 FT
ALS	VOR 114.700	54 54 19.49N 009 56 36.16E	FL 50/60 NM, 80 NM 313°-063° MAG, and 80 NM 198°-243° MAG	TL	L 384	56 18 01.46N 010 37 07.22E	20 NM
AU	L 346	55 19 27.58N 008 19 06.08E	15 NM	TNO	VOR/DME 117.400/121X	55 46.27N 011 26.21E	FL 50/60 NM DME ELEV - 11.9 FT
BEL	DME 114.65.90Y	55 47 28.45N 012 05 44.74E	FL105 - 1000FT/60NM DME ELEV 135.0 FT	VAM	DME 110.050/37X	55 26.17N 009 20.06E	FL195/60NM DME ELEV 174.5 FT
CDA	DME 114.900.96X	55 00.05N 012 22.45E	FL 50/60 NM. DME ELEV 90.2 FT	VJ	L 328	55 59 19.13N 009 25 27.97E	15 NM
ESE	DME 116.600/113X	55 31.21N 008 33.31E	100 NM DME ELEV 175.5 FT	VO	L 321	55 13.28.74N 009 16 25.36E	25 NM
FAU	L 334	55 01 41.49N 014 54 01.79E	20 NM	**Sweden**			
KAR	TACAN 37X	56 17 48.03N 009 00 39.99E	FL 50/200NM DME ELEV 172.8 FT	AH	L 417	56 15 58.2N 012 54 52.7E	15 NM
KAS	DME 112.500/72X	55 35 25.87N 012 36 48.91E	FL 50/60 NM. DME ELEV 28.9 FT	KD	L 315	55 52 16.9N 014 04 41.4E	15 NM
KD	L 357	55 26 35.87N 009 20 05.42E	15 NM	LAV	DVOR/DME 114.60/60X	57 39 22.0N 012 17 23.5E	FL 50/100 NM DME ELEV 574 FT
KOR	VOR/DME 112.800/75X	55 26 22N 011 37 54E	FL 50/60 NM. DME ELEV 136.2 FT	LB	L 370.5	56 20 47.6N 012 49 58.9E	25 NM
KV	DME 52X	55 35 10.91N 012 07 09.24E	DME ELEV 170.6 FT	LT	L 336	56 47 49.3N 012 50 32.8E	25 NM
LME	DME 115.350/100Y	55 59 34N 008 21 16E	FL195/60NM DME ELEV 76.1 FT	MF	L 421	56 39 08.9N 012 48 30.2E	15 NM
ODN	DME 115.500/102X	55 34 52N 010 39 11E	FL 50/60 NM 010°-163° MAG, and 60 NM 231°-247° MAG. DME ELEV 24.0 FT. DME ODN 102X reduced range to 24 NM in direction 198 degrees at 3000 FT or below.	NL	L 369	57 43 50.1N 012 20 39.2E	15 NM
RAM	DME 111.850/55Y	56 28 42N 008 11 15E	FL 50/60NM. DME ELEV 60.4 FT	OEM	NDB 363	55 59 23.1N 014 08 03.1E	30 NM
RK	L 368	55 37 23.27N 011 59 49.81E	30 NM	SL	L 342	57 35 41.5N 012 13 13.4E	15 NM
ROE	VOR 112.000	55 03 06.08N 014 45 31.29E	FL 50/80 NM. 017°-152° MAG 190 NM. DME INFO from ROE TACAN	SUP	VOR/DME 113.007/X	55 32 04.3N 013 22 46.5E	FL 50/80 NM. DME ELEV 259 FT.
				SVD	DME 116.20/106X	56 10 08.1N 012 34 25.3E	FL 50/100 NM DME ELEV 45 FT
				Germany			
				KIL	NDB 353	54 22 39.29N 010 07 12.08E	30 NM
				TRT	DME 108.45/21Y	54 30 39.49N 013 14 37.58E	FL 50/60 NM DME ELEV 22 FT

Public Holidays (HOL)

New Years Day (1 JAN)
Maundy Thursday (THU before Easter)
Good Friday (FRI before Easter)
Easter Monday (MON after Easter)
Ascension Day (6th THU after Easter)
Whit Monday (MON after Whit Sunday)
Christmas (25 DEC)
Boxing Day (26 DEC)

Note: Some administrative services, banks and alike may be closed on the following days:
Labour Day (1 MAY)
Constitution Day (5 JUN)
Day of Christmas Eve (24 DEC)
Day of New Years Eve (31 DEC)
FRI after Ascension Day (6th FRI after Easter)

Navigation Warnings etc.

Prohibited, Restricted, and Danger Areas

Definitions

a. Prohibited area (P): Area within which flight is prohibited.
b. Restricted area (R): Area within which flight may take place only on certain conditions, e.g. after prior permission from ATS.
c. Danger area (D): Area within which activities dangerous to flights may take place, e.g. gun firing.

These areas are identified by two nationality letters EK, the letter P, R or D and a number.

Information about activities

Information about the period and height within which activities actually take place may be obtained from 1100 (1000) the day before. However, activities on SLN and MON may be obtained already friday from 1100 (1000). For information contact ACC (CS Copenhagen wind), FIS (CS Copenhagen Information), and the briefing offices at the following airports/aerodromes:

Aalborg	København/Kastrup
Aarhus	København/Roskilde
Billund	Lolland Falster/Maribo
Bornholm/Rønne	Odense /
Esbjerg	Hans Christian Andersen Airport
Karup/Midtjylands Lufthavn	Stauning
Kolding/Vamdrup	Sønderborg

Information about active areas and NOTAM can be obtained on the Internet: https://briefing.naviair.dk.

VFR-flying with Military Aircraft

VFR-flying with military aircraft takes place within Kobenhavn FIR and over the Island of Bornholm. In airspace where the speed limitation 250 KT is valid, military fighter-aircraft will adjust to the aerodynamic characteristics of the aircraft and the mission profile. Such adjustments will comply with the 250 KT speed limitation in all cases.

Temporary Segregated Areas (TSA)

Within the areas shown in figure 1. special training flights with military fighter aircraft may take place periodically. The training flights are conducted with due regard to civil traffic, but the nature of the air operations concerning right-of-way may not always be complied with. Information about the period and height where activities are planned to take place are notified by NOTAM. Information about actual usage can be obtained by relevant ATS units.
VFR flights should avoid entering an active TSA. If entry cannot be avoided, two-way radio communication should be established with relevant ATS-unit. The ATS-unit will forward the information to the military ATS-units concerned.

Temporary Reserved Areas (TRA)

Within the areas shown in figure 1. special training flights with military fighter aircraft may take place periodically. The training flights are conducted with due regard to civil flights but the Rules of the Air procedures concerning right-of-way may not always be complied with. Information about actual usage can be obtained by relevant ATS units.
VFR flights in controlled airspace penetrating an active TRA will be separated from special training flights with the prescribed separation minima. For IFR flights in uncontrolled airspace penetrating an active TRA the ATS-unit in contact with the IFR flight, will forward that information to the military ATS-units concerned.
VFR flights should avoid entering an active TRA. If entry cannot be avoided, two-way radio communication should be established with relevant ATS-unit. The ATS-unit will forward the information to the military ATS-units concerned.

Fixed Obstacles

a. All known fixed obstacles of a height of 328 FT (100 M) AGL or more are shown on ANC 1:500 000.
Fixed obstacles of a height less than 328 FT (100 M) AGL are shown if it is deemed necessary.
b. Fixed obstacles of a height of 492 FT (150 M) AGL or more are marked.
Fixed obstacles of a height less than 492 FT (150 M) AGL are marked if it is deemed necessary.

Cable Launching of Glider and Hang Glider

Cable launching may take place at some sites up to a height of 2500 FT AGL. The cable forms an almost invisible obstacle during launch as well as when falling to the ground. After release, the cable will fall to the ground in the direction with the wind, away from the winch. Normally the cable will fall within the end of the site, but situations may occur where the cable will fall outside the site.
Collision with the cable may cause damage to an aircraft, in worst case be fatal. A safety distance of 1 NM from the position of the winch is considered to be sufficient. Frequency 130.130 MHZ is assigned for operational communication between the launch site and ultra light aircraft in Kabenhavn FIR.
Glider and hang glider sites are shown on ANC 1:500 000.

Ballooning

Frequency 122.655 MHZ is assigned for operational communication between balloons and ground personnel.

Parachuting

Parachuting may take place at many locations throughout the country. Locations, known by the Danish CAA, as being frequently used are shown on ANC 1:500 000. Frequency 130.130 MHZ is assigned for operational communication between parachuting and ground personnel. NOTAM about parachuting will be issued only in cases of special and intensive activity and if the Danish CAA has been informed thereof.

Helicopter frequencies

The following frequencies are assigned only for communication between helicopter and ground personnel:
- For medical operations: 121.080
- For helicopter hoist operations: 125.405

The frequencies can be used up to 2000 FT on Danish territory.

Helicopter Operations in the North Sea

Helicopter operations to, from and between oil and gas installations in the North Sea are taking place on a 24 hours basis, under IMC as well as VMC, and often with an underslung load, and in heights up to FL 85.

Helicopter routes (HR)

HR have been established for the most used helicopter tracks in that part of the North Sea, where AFIS is not provided by Denmark.

Other air traffic than civil helicopter operations are advised

a. to avoid flying along or in close vicinity of a HR, and
b. to cross a HR at an angle as close to 90° as possible, and to keep an alert look out.

The following frequency (MHZ) is assigned only for communication between helicopter and helideck personnel on/near installations in the North Sea:
- For Helicopter Operations North of 56 00 00N 131.780
- For Helicopter Operations South of 56 00 00N 123.455

The frequency can be used up to FL 100 in the North Sea.
The HR and the fixed oil/gas installations are shown in figure 2.

"Cold Flaring" in the North Sea.

In connection with the exploration and production of oil and gas in the North Sea, "Cold Flaring" may occur which could endanger air traffic.

Gas escaping from the oil production will normally be burned off. When the oil production is restarted after a shut down period, the purge of the installations to the atmosphere it is necessary to purge the pipework and vessels before ignition of the gas. During this procedure, called "Cold Flaring", large amounts of gas will be pouring into the atmosphere, creating an explosive mixture. The extend of the mixture is depending on the actual weather conditions.

"Cold Flaring" may take place from all fixed and mobile oil- and gasinstallations.

Actual information about "Cold Flaring" may be obtained from Tyra Information within hours of service.

Air traffic is advised to pass installations from which "Cold Flaring" is taking place at a lateral distance of 3 NM or more or at an altitude of 3.000 FT MSL or above.

Risk of Explosion in the Vicinity of North Sea Oil and Gas Installations

In connection with perforation of underground wells, explosive charges are released by means of radio waves.

Radio waves covering the whole frequency spectrum might release an explosion if they are received when detonators are being inserted or removed.

To avoid inadvertent explosion, which can be a risk to the crew on the installation and damage the installation, air traffic is strongly requested to pass all fixed and mobile installations at a lateral distance of 1 NM or more or at an altitude of 3000 FT MSL or above. For fixed oil and gas installations, see AD 3-1.

Burning of Gas and Condensates from Flare Stacks

From the flare stacks located at the positions listed below escape and burning of gas and condensates may take place occasionally. See also ENR 5.4.

NNV of Vande at PSN 55 40 00N 008 21 59E *
S of Kalundborg at PSN 55 39 13N 011 06 01E *
SW of Egtved at PSN 55 35 57N 009 13 51E
N of Viborg at PSN 56 38 25N 009 25 03E *
SE of Nørager at PSN 56 12 37N 011 59 06E
NE of Skjern at PSN 55 52 38N 011 37 25E

Due to high temperature and risk of explosion it is recommended to avoid overflying below 2000 FT MSL.
The flare stacks are shown on ANC 1:500 000.

Bird Migration

General

Bird migration occurs during the whole year, but culminates in the periods end of March to Mid-May (spring migration) and beginning of September to Mid-November (autumn migration).

Spring Migration

Spring migration culminates in the period end of March to Mid-May. Peak numbers for most species occur in April. The most important factors inducing heavy migration are a rise in temperature over Central and Western Europe, light winds, and southerly winds.
At night, migration is generally in a broad outline covering the entire country and its surrounding waters, with mean direction NNE. Most birds come from Central and Western Europe. In daylight migration tends to concentrate along guiding coasts. The most important points of concentration are:

a. Skagen 57 45N 010 35E
b. Fornæs 56 25N 010 55E
c. North-East Fyn 55 20N 010 45E
d. North and East Sjælland 56 00N 011 40E - 55 20N 012 30E

Generally the altitude of migration at night is higher than by day. At night the average altitude is about 3000 - 5000 FT, by day 1000 - 3000 FT.

Autumn Migration

Autumn migration culminates in the period beginning September to Mid-November. Peak numbers for most species occur in October. The most important factor inducing heavy migration is fall in temperature over Central and Northern Scandinavia. High intensity coincide also with winds from NNE, light winds, little cloud-cover and high atmospheric pressure.
At night, migration is in a broad outline covering the entire country and its surrounding waters with mean direction south. Most birds come from southern part of Norway and southern part of Sweden. By day, migration tends to concentrate in the eastern part of Denmark and along guiding coasts. The most important points of concentration are:

a. Falsterbo (southern Sweden) 55 25N 012 50E - 55 20N 012 30E and Stevns
b. Gedser Rev/Rødsand 54 35N 011 55E - 54 40N 011 20E
c. Skagen 57 45N 010 35E
d. South Langeland 54 45N 010 40E
e. Blåvand 55 35N 008 05E

Generally the altitude of night migration is higher than by day. At night the average altitude is about 3000 - 5000 FT, by day about 1000 - 3000 FT.

Numbers of Birds

At least 100 million birds pass over Denmark and its surrounding waters during autumn. Smaller passerines are dominating. Several species occur in great numbers and are most hazardous to aircraft, e.g. starlings, thrushes and finches. Very numerous and hazardous are also crowbirds, ducks, gulls, waders, pigeons and birds of prey, occurring from tens of thousands to several millions.

Kobenhavn FIR. General

VFR flight within Kobenhavn FIR may normally take place at FL 195 and below. ATS airspace (FIR, CTA, LTA, TMA, CTR and FIZ) below FL 200 are shown on the chart. See also figure 3.
ATS-routes are established as follows:
a. Above 3000 FT MSL in the eastern part of the FIR (east of APRIX 8°E).
b. Above FL 195 in the western part of the FIR (the North Sea Area).
c. Helicopter routes are established in the North Sea Area below FL85 as shown in figure 2.
ATS-routes are described in AIP Denmark, which is available also on the Internet: https://aim.naviair.dk

ATS Airspace other than FIR, CTA, TMA and CTR

In addition to the airspace types, FIR, CTA, TMA and CTR, the following ATS airspace are established within Kobenhavn FIR as described hereafter.

Local ATS Area (LTA)

Definition
An airspace of defined dimensions, extending upwards from the surface of the earth or water to a specified upper limit within which ATS is provided by the local ATS-unit.

Transponder Mandatory Zone (TMZ)

Definition
Transponder Mandatory Zone (TMZ) means an airspace of defined dimensions wherein the carriage and operation of pressure-altitude reporting transponders is mandatory.

Procedures
All flights operating in airspace designated by the competent authority as a transponder mandatory zone (TMZ) shall carry and operate SSR transponders capable of operating on Modes A and C or on Mode S, unless in compliance with alternative provisions prescribed for that particular airspace by the ANSP.

Designation
The airspace within Kobenhavn FIR designated as TMZ is reflected in AIP Denmark ENR 1.4 table 1 ATS airspace classification.

Radio Mandatory Zone/RMZ

Definition
Radio mandatory zone (RMZ) means an airspace of defined dimensions wherein the carriage and operation of radio equipment is mandatory.

Procedures
VFR flights operating in parts of Classes E, F or G airspace and IFR flights operating in parts of Classes F or G airspace designated as a radio mandatory zone (RMZ) by the competent authority shall maintain continuous air- ground voice communication watch and establish two-way communication, as necessary, on the appropriate communication channel, unless in compliance with other provisions prescribed for that particular airspace by the ANSP.
Before entering a radio mandatory zone, an initial call containing the designation of the station being called, call sign, type of aircraft, position, level, the intentions of the flight and other information as prescribed by the competent authority, shall be made by pilots on the appropriate communication channel.

Designation
Within Kobenhavn FIR, FIZ and airspace Class E and G above FL 95 are designated as RMZ. RMZ is reflected in AIP Denmark, ENR 2 and AD 2 item 17.

Flight Information ZoneFIZ

Definition
An airspace of defined dimension within which aerodrome flight information service and alerting service is promoted safe and efficient flights.

Note: FIZ is also designated as Radio Mandatory Zone (RMZ), reference to Civil Aviation regulation BL 7-100 and ENR 1.4 item 3.

Procedures
a) IFR and VFR flights operating in a FIZ shall maintain continuous air-ground voice communication watch and establish two-way communication, as necessary, on the appropriate communication channel, except as may otherwise be arranged with the relevant AFIS unit.

b) Before entering an FIZ, an initial call containing the designation of the AFIS unit being called, callsign, type of aircraft, position, level and the intentions of the flight shall be made by pilots on the appropriate communication channel.Changes to level and track - if any - shall be reported immediately to the AFIS unit.

c) Except as may otherwise be arranged with the relevant AFIS unit, a pilot, who intends to cross an FIZ or operate locally, shall, prior to entering an FIZ, establish two-way voice communication with the AFIS unit.

d) Except as may otherwise be arranged with the relevant AFIS unit, a pilot who intends to land on or take-off from the aerodrome ultra light or motor hang gliding aircraft in Kobenhavn FIR shall establish two-way voice communication with the AFIS unit.

Tyra FIZ is given in AIP Denmark, ENR 2.2 and FIZ for inner aerodromes are given in AD 2 item 17.

Flight within LTA, TMA, CTR and FIZ outside Published Hours of Service

When LTA, TMA, CTR and FIZ are not established H24, information as to whether the area concerned is established shall be obtained from the relevant ATS-unit as given below.

Aarhus LTA, TMA and CTR	ATS Unit
Esbjerg FIZ	APP Esbjerg
Odense FIZ	ACC Kobenhavn
Ranne TMA and CTR	ACC Malmö
Stauning FIZ	APP Billund
Sønderborg FIZ	ACC Kobenhavn
Tyra FIZ	ACC Kobenhavn
Vamdrup FIZ	APP Skrydstrup

Hours of service can be found in the VFR Flight Guide (VFG), which is also available on the Internet: https://aim.naviair.dk

ACC Telephone Numbers

ACC Kobenhavn +45 32 46 23 38
ACC in Sweden (ATC Malmö) +46 (0)40 - 18 06

(Telephone numbers for ATS-units at aerodromes, see list of public aerodromes).

Radio Communication and Secondary Surveillance Radar

Frequency Protection

To avoid harmful interference of air - ground communications, aircraft are not permitted to establish connection with ground stations outside the protected areas as stated in the following:

a. For TWR and AFIS not outside 4000FT/25 NM.
However:
1. For Bornholm/Rønne TWR, Esbjerg Information and Sonderborg Information FIS, 100/40 NM applies.
2. For Tyra Information 6000 FT/40 NM applies.

b. For air-ground stations on mines and public aerodromes not outside 4000FT/25 NM.
c. For APP not outside FL 250/50 NM.
However:
1. for Aalborg APP FL 250/60 NM applies
2. for Aarhus APP FL 250/60 NM applies.
3. for Roskilde APP FL 150/50 NM applies.

ATIS Frequency

- Aalborg	H24	AIRPORT INFORMATION	120.480 MHZ
- Aarhus	H24	AIRPORT INFORMATION	125.155 MHZ
- Billund	H24	ARRIVAL INFORMATION	118.780 MHZ
- Billund	H24	DEPARTURE INFORMATION	129.105 MHZ
- Karup	H24	AIRPORT INFORMATION	120.580 MHZ
- Kastrup	H24	ARRIVAL INFORMATION	122.755 MHZ
- Kastrup	H24	DEPARTURE INFORMATION	122.855 MHZ
- Roskilde	0600-2100 (0500-2000)	AIRPORT INFORMATION	123.805 MHZ
- Skrydstrup	H24	AIRPORT INFORMATION	133.905 MHZ

Air-to-Air Frequency

The frequency 129.805 MHZ is assigned for air-to-air operational communication within Kobenhavn FIR up to FL 100.

Guarding of the VHF Emergency Frequency 121.500 MHZ

Aircraft flying over the North Sea and Skagerrak within Kobenhavn FIR, shall continuously guard the VHF emergency frequency 121.500 MHZ, except for such periods when aircraft is carrying out communication on other VHF frequencies, or when airborne equipment limitations or oxygen duties do not permit simultaneous guarding of two frequencies.

Glider Frequencies

Frequencies for operational communication air-to-air and air-to-ground shall, as far as possible, be used as shown hereafter (See Figure 4):

- Jylland - North:	123.380 MHZ
- Jylland - Middle:	122.480 MHZ
- Jylland - South and Fyn:	129.980 MHZ
- Sjælland - West and Lolland/Falster:	123.430 MHZ
- Sjælland - East/Bornholm:	122.655 MHZ

Secondary Surveillance Radar (SSR)

SSR Requirements
Aircraft performing VFR flights within Danish ATS Air Space classified C (Billund TMA and TMAs within Copenhagen Area) and within airspace designated as Transponder Mandatory Zone (TMZ), shall carry a serviceable SSR transponder with Modes A and C or Mode S. Exemption from the requirements may, for individual flights, be granted by the appropriate ATC unit.

Radio Communication Failure Procedure
In the event of a radio communication failure, a VFR-flight shall select Mode-A, Code 7600 and follow established lost communication failure procedures. Subsequent conversion of ATS to such flight will be based on those procedures.
Note: Continuous monitoring of responses on Mode-A, Code 7600 is provided.

Normal Operating Procedures
a. The provisions of ICAO (PANS-